MDLEDTMINSTALLATION INSTRUCTIONS





MDLED1X Ceiling Opening : 6¹/₂ X 5⁷/₈"

MDLED2X Ceiling Opening : 11¹/2 X 5⁷/8"



MDLED3X Ceiling Opening : 16¹/₂ X 5⁷/₈"



MDLED4X Ceiling Opening: 21¹/₂ X 5⁷/₈"

IMPORTANT

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

RAB fixtures must be wired in accordance with the National Electrical Code and all applicable local codes. Proper grounding is required for safety. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED. **WARNING: Make certain power is OFF before installing or maintaining fixture. No user serviceable parts inside.**



FRAME MOUNTING

For New Construction, mount the Frame before mounting the Housing. This fixture can be installed with ceiling temperature not exceeding 40° C and with minimum plenum height of $7^{1}/_{2}$ ".

- 1. Prepare the mounting surface with appropriate cut out dimension for your unit. Cut-out must be accurate not undersized or oversized.
- 2. Insert through **C-Channels** (sold separately) or other bar stock, in **Butterfly Brackets** and secure accordingly. Consult local building codes for final support of fixture.
- 3. Position the frame on C-Channel and secure C-Channel to the Grid as shown in Fig 1.
- 4. Remove appropriate **Knock out** on Junction box. Press **Clip** to open the **Junction Box**.
- 5. Feed the supply wires through **Knock out** hole and connect to the fixture wire. See wiring section for details.
- 6. For different ceiling thickness, loosen the **Wing Nut** and slide the **Butterfly Bracket**. If necessary remove the **Wing Nut**, insert and screw in different hole provided on the **Butterfly Bracket** (Fig:1). Adjust so that the **Frame** is flush with the finished ceiling surface. Tighten the **Wing nuts**.

HOUSING MOUNTING - NEW CONSTRUCTION

- 1. For New Construction Units, orient the Housing in the Frame such that the Splice Plate is closer to connector.
- 2. Feed connector from Frame through splice plate. Provided Female connector not used in this assembly.
- 3. Adjust the length of Mounting Flag of Housing by positioning the Flag Screw such that Housing is close to ceiling surface. If necessary, remove part of flag. (Fig 2)
- 4. To secure fixture into ceiling, tighten the Long Flag Screw from inside the Housing. Mounting Flag should be snug tight against ceiling. DO NOT OVERTIGHTEN SCREWS.

HOUSING MOUNTING - REMODELER

1. For the Remodeler units, prepare the mounting surface with Cut-off dimensions.

MDLED1X	Cut-Out : 6 ¹ / ₂ X 5 ⁷ / ₈ "
MDLED2X	Cut-Out: 11 ¹ / ₂ X 5 ⁷ / ₈ "
MDLED3X	Cut-Out: 16 ¹ / ₂ X 5 ⁷ / ₈ "
MDLED4X	Cut-Out: 21 ¹ / ₂ X 5 ⁷ / ₈ "

- 2. The Female Splice is provided separately. Connect the Supply Wires to the provided splice. Use connectors per Local code.
- 3. To secure Housing follow steps 3-4 in New Construction section above.

GEAR TRAY MOUNTING

- 1. Orient the Gear Tray such that the Male connector on Gear Tray is close to Splice Plate.
- 2. Connect the tether(s) from the Rough-in to the Gear Tray for Hands Free mounting.
- 3. Pull Female Connector conduit through Rough-in opening. Raise Gear Tray towards opening and connect to Male Connector conduit.
- 4. Press Springs Pins inward and slide Gear Tray into holes on Rough-in one side at a time.
- 5. There are three possible hole positions for the Gear Tray with reference to Ceiling surface.
- 6. To secure the Gear Tray ensure the Spring Pins are fully engaged into the end plate holes.
- 7. To adjust LED Head, loosen the Locking Knob by rotating. Orient the Led Head at desired angle and tighten the Locking Knob.



ON-OFF WIRING

Universal voltage driver permits operation at 120V thru 277V, 50 or 60 Hz. For Non-Dimming, follow the wiring directions as in fig. 2.

- 1. Connect the black fixture lead to the (+) LINE supply lead.
- 2. Connect the white fixture lead to the (-) COMMON supply lead.
- 3. Connect the GROUND wire from fixture to supply ground.



DIMMABLE WIRING

Universal voltage driver permits operation at 120V thru 277V, 50 or 60 Hz. For dimmable drivers follow the wiring directions as in fig. 3.

- 1. Connect the GROUND wire from fixture to supply ground.
- 2. Connect the black fixture lead to the (+) LINE supply lead. For 2x, 3x and 4x units, Red and Black are two (+) lines provided.
- 3. Connect the white fixture lead to the (-) COMMON supply lead.
- 4. Connect the purple fixture lead to the (V+) DIM lead.
- 5. Connect the gray fixture lead to the (V-) DIM lead.



CLEANING & MAINTENANCE

CAUTION: Be sure fixture temperature is cool enough to touch. Do not clean or maintain while fixture is energized.

- 1. Do not touch or clean the LED. Do not leave LEDs uncovered.
- 2. Do not clean any fixture surface with wood base cleaning material such as paper towels or tissues.

TROUBLESHOOTING

- 1. Check that the line voltage at the fixture is correct. Refer to wiring directions.
- 2. Is the fixture grounded properly?

ACCESSORIES

All accessories available in Black and White colors

SNOOT1*	1 ¹ / ₂ " Door with 20° Lens
SNOOT2*	2 ¹ / ₂ " Door with 20° Lens
BEZMDLED20	Door Reflector kit with 20° Lens
BEZMDLED30	Door Reflector kit with 30° Lens
BEZMDLED40	Door Reflector kit with 40° Lens

* Note: White Snoot is provided with black insert for glare reduction.

Note: These instructions do not cover all details or variations in equipment nor do they provide for every possible situation during installation, operation or maintenance.





Gel installation directions



This is how you install a color lens gel on an $\mathsf{MDLED}^{\mathsf{M}}$

1. Pull the bezel out of the head of the fixture and set head aside.

2. Pry spring ring from inside of bezel with a screwdriver and set aside.

3. Remove reflector and lens from bezel and set aside.

4. Place lens on gel sheet and use lens as template to cut color gel filter to proper size. Trim off any excess material.











5. While holding bezel, insert cut gel filter first. Then insert lens on top of gel making sure the shiny side of the lens is facing down (matte side should be facing up).











6. Drop reflector back into bezel.

 Place spring ring back inside the bezel.
IMPORTANT: Make sure spring ring snaps into lower/bottom groove of the inside of the bezel. 8. Once spring ring is on lower/bottom groove, snap bezel back into the head of the fixture.



Before





After