




# HAZLED™ WALL INSTALLATION INSTRUCTIONS

## WIRING

**CAUTION: Make sure the supply voltage is the same as the luminaire voltage.**

Universal voltage driver permits operation at 120 to 277VAC, 50 or 60Hz.

1. Connect the black fixture lead to the (+) LINE supply lead.
2. Connect the white fixture lead to the (-) COMMON supply lead.
3. Connect the bare copper Ground wire from fixture to supply ground.



## CLEANING & MAINTENANCE

**CAUTION: Be sure housing and lens temperature are cool enough to touch. Do not clean or maintain while fixture is energized.**

1. Clean glass lens with non-abrasive glass cleaning solution.
2. Do not open fixture to clean the LED. Do not touch the LED.
3. All gaskets seals must be clean and undamaged.

## TROUBLESHOOTING


1. Check that the line voltage at fixture is correct. Refer to wiring directions.
2. Be sure fixture is grounded properly.

## ACCESSORIES

### GUARDS

- with Die Cast Guard.....suffix "-DG"
- with Wire Guard.....suffix "-G"

### HAZBLED26 with clear globe




All results are according to IESNA LM-79-2008: Approved Method for the Electrical and Photometric Testing of Solid-State Lighting. The U.S. Department of Energy (DOE) verifies product test data and results.

Visit [www.lightingfacts.com](http://www.lightingfacts.com) for the *Label Reference Guide*.

Registration Number: WVMA-44FC6K (5/20/2014)  
 Model Number: HAZ\*LED26C / HAZ\*LED26CF  
 Type: Luminaire - Industrial

### HAZBLED42 with clear globe



All results are according to IESNA LM-79-2008: Approved Method for the Electrical and Photometric Testing of Solid-State Lighting. The U.S. Department of Energy (DOE) verifies product test data and results.

Visit [www.lightingfacts.com](http://www.lightingfacts.com) for the *Label Reference Guide*.

Registration Number: WVMA-QICVEZ (5/20/2014)  
 Model Number: HAZ\*LED42C / HAZ\*LED42CF  
 Type: Luminaire - Industrial

Note: These instructions do not cover all details or variations in equipment nor do they provide for every possible situation during installation operation or maintenance.